
Michigan Supreme Courts Video Project Polycom Group Series Quick Tips Reference Information April 6, 2019



Remote Control Description

- 1 LED IR emitter
- 2 Decrease speaker volume
- 3 Increase speaker volume
- 4 Zoom camera out
- 5 Zoom camera in
- 6 Select
- 7 Menu navigation and Camera Control (Up, Down, Left, and Right)
- 8 Backspace and Previous Page
- 9 Soft Menu
- 10 Home Screen (Main Menu)
- 11 Place or answer a call (Also Power On)
- 12 End or reject a call (Also Power Off)
- 13 Keypad numbers or letters
- 14 Preset camera selection in camera mode
- 15 * or dot
- 16 # or @ symbol
- 17 Mutes microphone
- 18 Rechargeable Battery (Not Shown)

Placing Calls and Call Control

- 1. Speed Dial Select entry on the **Home** Screen
- State Directory Press Place a Call Select
 Contacts and then either select the desired entry
 through the alphabetic list OR use the Search field
 to do a partial name search for the desired contacts
 entry.
- Manual Call Press Place a Call and enter the destination dialing string in the field and press the Place a Call button
 - Dialing String Formats:
 - > Extension@IP (e.g. 135@12.232.9.10)
 - > IP##Extension (e.g. 12.232.9.10##135)
 - > IP Only (e.g. 75.41.109.236)
- 4. <u>Answer a Call</u> -Press **Answer** on the remote control.
- 5. End a Call Press End on the remote control.
- 6. <u>Mute Your Microphone</u> Press **Mute** on the remote control or on the Mic Array
- 7. <u>Adjust the Volume</u> Press **Speaker Volume** on the remote control.
- 8. <u>Change Camera View</u> Quickly press and release Preset number during a call to change views
- 9. <u>Display Content</u> Connect content HDMI cable to PC or alternate device. Audio and video play .

Test Calls (Also in Directory)

- Test 4000 HOJ 12.232.9.10##135
- Test JE 8000 75.41.109.236
- Test 6000 MDOC 167.240.254.175##67002
- Devices auto answer 24 x 7

Supreme Court Video Support Resource

Jim Ewing 313-515-3334 jebc1@jebc.onmicrosoft.com